



## Temperature & Humidity Sensor

YS8003-UC

Quick Start Guide

Revision Dec. 19, 2023

### A Welcome!

Thank you for purchasing YoLink products! We appreciate you trusting YoLink for your smart home & automation needs. Your 100% satisfaction is our goal. If you experience any problems with your installation, with our products or if you have any questions that this manual does not answer, please contact us right away. See the Contact Us section for more info.

Thank you!

YoLink Customer Support

The following icons are used in this guide to convey specific types of information:



Very important information (can save you time!)



Good to know info but may not apply to you

### B Before You Begin

Please note: this is a quick start guide, intended to get you started on the installation of your Temperature & Humidity Sensor. Download the full Installation & User Guide by scanning this QR code:



Installation & User Guide

You can also find all guides and additional resources, such as videos and troubleshooting instructions, on the Temperature & Humidity Sensor Product Support page by scanning the QR code below or by visiting:

<https://www.yosmart.com/support/YS8003-UC>



Product Support  
Support produit  
Soporte de producto




Your Temperature & Humidity Sensor connects to the internet via a YoLink hub (SpeakerHub or the original YoLink Hub), and it does **not** connect directly to your WiFi or local network. In order for remote access to the device from the app, and for full functionality, a hub is required. This guide assumes the YoLink app has been installed on your smartphone, and a YoLink hub is installed and online (or your location, apartment, condo, etcetera, is already served by a YoLink wireless network).



To provide years between battery changes, your sensor refreshes at least once an hour or more frequently if the SET button is pressed or if the temperature or humidity change meets refresh criteria as explained in the user guide.

### C In the Box



Temperature & Humidity Sensor




Quick Start Guide




Two AAA Batteries (Installed)

### D Required Items

You may require these items:



Medium Phillips Screwdriver



Hammer





Nail or Self Tapping Screw



Double-sided Mounting Tape

### E Get to Know Your Temp & Humidity Sensor




### E Get to Know Your Temp & Humidity Sensor, Cont.

LED Behaviors

- Blinking Red Once, then Green Once  
Device turned on
- Blinking Red And Green Alternately  
Restoring to Factory Defaults
- Blinking Green Once  
Switching temperature mode
- Blinking Green  
Connecting to Cloud
- Slow Blinking Green  
Updating
- Blinking Red Once  
Device alerts or device is connected to the cloud and is functioning normally
- Fast Blinking Red Every 30 Seconds  
Batteries are low; please replace the batteries

### F Power Up



Turn on the Temperature & Humidity Sensor by briefly pressing the SET button, until you see the LED flash red then green.

### G Install the App

If you are new to YoLink, please install the app on your phone or tablet, if you have not already. Otherwise, please proceed to the next section.

## G Install the App, Cont.

Scan the appropriate QR code below or find the "YoLink app" on the appropriate app store.



Apple phone/tablet  
iOS 9.0 or higher

Android phone/  
tablet 6.0 or higher

Open the app and tap **Sign up** for an account. You will be required to provide a username and a password. Follow the instructions, to set up a new account. Allow notifications, when prompted.

You will immediately receive a welcome email from no-reply@yosmart.com with some helpful information. Please mark the yosmart.com domain as safe, to ensure you receive important messages in the future.

Log in to the app using your new username and password.

The app opens to the **Favorite** screen. This is where your favorite devices and scenes will be shown. You can organize your devices by room, in the **Rooms** screen, later.

Refer to the full user guide and online support for instructions on the use of the YoLink app.

## H Add the Sensor to the App

1. Tap **Add Device** (if shown) or tap the scanner icon:

Scanner icon



2. Approve access to your phone's camera, if requested. A viewfinder will be shown on the app.

## H Add the Sensor to the App, Continued

3. Hold the phone over the QR code so that the code appears in the viewfinder. If successful, the **Add Device** screen will be displayed.

4. You can change the device name and assign it to a room later. Tap **Bind device**.

## I Install the Temperature & Humidity Sensor

### Environment Considerations:

Determine an appropriate location for your sensor.



**Please note:** the Temperature & Humidity Sensor is intended for indoor use, at dry locations. Refer to the product support page for the full environmental specifications.

- Consider our Weatherproof Temperature & Humidity Sensor for outdoor locations.
- If you plan to use this sensor in a freezer, ensure the sensor does not get wet during defrosting cycles.

### Location Considerations:

If placing the sensor on a shelf or countertop, ensure it is a stable surface. If hanging or mounting the sensor on a wall, ensure the mounting method is secure, and the location does not subject the sensor to physical damage. The warranty does not cover physical damage.

- ▶ Do not place the sensor where it may get wet
- ▶ Do not place the sensor where it will be subjected to direct sunlight
- ▶ Avoid placing the sensor near HVAC grilles or diffusers

## I Install the Temperature & Humidity Sensor, Cont.

1. Before installing or placing your sensor, ensure the display mode is correct for your application. To switch between Celsius and Fahrenheit display mode, briefly press the SET button (on the rear of the sensor).

2. If placing the sensor on a shelf or countertop or other stable surface, place the sensor where desired, then proceed to the next section.

3. Before mounting or hanging the sensor on the wall or vertical surface, determine your desired method:

- Hang the sensor from a nail or screw or small hook
- Hang or mount the sensor by other methods, such as 3M brand Command hooks
- Secure the sensor to the wall using mounting tape, Velcro or similar methods. If affixing something to the rear of the sensor, be aware of the impact of covering the SET button or LED, and allow for battery replacement in the future.

4. Mount or hang the sensor on the wall or vertical surface using your desired method. (Insert a screw into the wall, hammer a nail into the wall, etc.)

5. Allow your sensor at least one hour to stabilize and report the correct temperature and humidity to the app. Refer to the full installation & user guide for instructions on calibrating your sensor, if it does not appear to indicate the correct temperature and/or humidity.

**Refer to the full Installation & User Guide, to complete the setup of your Temperature & Humidity Sensor.**

## J Contact Us

We are here for you, if you ever need any assistance installing, setting up or using a YoLink app or product!

Need help? For fastest service, please email us 24/7 at [service@yosmart.com](mailto:service@yosmart.com)

Or call us at **831-292-4831** (US phone support hours: **Monday - Friday, 9AM to 5PM** Pacific)

You can also find additional support and ways to contact us at: [www.yosmart.com/support-and-service](http://www.yosmart.com/support-and-service)

Or scan the QR code:



Support  
Home Page

Finally, if you have any feedback or suggestions for us, please email us at [feedback@yosmart.com](mailto:feedback@yosmart.com)

Thank you for trusting YoLink!

YoLink Customer Support

**YOLINK**

25172 Arctic Ocean Drive, Suite 106  
Lake Forest, CA 92630

© 2023 YOSMART INC. CALIFORNIA, USA